

Driver Installation Manual

Table of Contents

Introduction.....	2
WinXP OS	3
1、 Install Driver by the Setup.exe.....	3
2、 Uninstall Driver by the Setup.exe	10
3、 Uninstall Driver by “Control Panel”	12
VISTA and Win7 OS	15
1、 Install Driver by the Setup.exe.....	15
2、 Uninstall Driver by the Setup.exe	18
3、 Uninstall Driver by “Control Panel”	21

Introduction

This doc mainly introduces the Driver installation and uninstallation by driver setup package. It contains the driver for XP 32, Vista32, Vista64, Win7-32 and Win7-64 OS.

The following chapter will show you how to install and uninstall the driver in the WinXP. Vista and Win7 is in the same way as WINXP.

WinXP OS


There is an example to help you.

1、 Install Driver by the Setup.exe


<1> double click the “Setup.exe”



<2> Click Next to continue




<3> Click Install to continue



<4> Click “Continue Anyway” to continue



<5> Click finish



<6> Click Next




SOMAGIC Confidential

<7> Click “Continue Anyway” to continue



<8> installing




<9> Click Next



<10> Click “Continue Anyway” to continue



<11> installing




<12> Completing the installation



2、 Uninstall Driver by the Setup.exe


<1> Double click the Setup.exe as the operation of installing, select remove, and click the Next.



<2> Click “Yes” to remove the Device.




<3> Wait a few seconds, click the Finish.



<4> Right click the Computer, and click the Manage



<5> In the “Computer Management”, click the “Device Manager” ①,
and right click the “SMI Grabber Device” ②, click the “Uninstall” ③




<5> Click “OK” to finish




3、 Uninstall Driver by “Control Panel”

<1> Click on **Start** menu and then go to **Control Panel**.

<2> Find **Add or Remove Programs** and click on it.



<3> A new window will be opened and find “**SMI Grabber Device**” from the installed program lists. Single click on it and then click on **Remove** button.



<4> Click on “Yes” to remove driver.




VISTA and Win7 OS


You can use our setup package to complete the driver installation and uninstall by these steps below:

1、 Install Driver by the Setup.exe


<1> Double click the Setup.exe as the XP, click the Next to continue.




<2> Click Install




<3> Installing



<3> Click “Install” to continue




<4> Finish the wizard




2、 Uninstall Driver by the Setup.exe


<1>Double click the Setup.exe as the operation of installing, select remove, and click the Next.




<2> Click “Yes” to remove the Device.



<3> Removing the device




<4> Wait a few seconds, click the Finish.




3、 Uninstall Driver by “Control Panel”

<1> Click on **Start** menu and then go to **Control Panel**.

<2> Find **Uninstall a programs** and click on it.



<3> A new window will be opened and find “SMI Grabber Device” from the installed program lists. Right click it and then click on **Uninstall** button.



<4> Click on “Yes” to remove driver.

